

INSTRUCTION MANUAL FOR NEXT LEVEL RACING® WHEEL STAND RACER



For assistance please contact: support@nextlevelracing.com www.nextlevelracing.com

Thank-you for purchasing a



WHEEL STAND RACER

If you require any support with your product please contact our friendly team at:

support@nextlevelracing.com for a prompt response.





-Please do not use power tools for assembly as over tightening can damage your frame.
-During assembly please be sure to have a washer positioned at the front of every bolt as pictured below.







WARNING

CHOKING HAZARD - Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths



What's In The Box:





WHEEL STAND RACER FRAME

For assistance please contact: support@nextlevelracing.com www.nextlevelracing.com



Step 1:



Unpack and unfold the wheel stand. Clip on the U-bolt to secure wheel support.





PEDAL ADJUSTMENT:



Tip – For quick pedal distance adjustment just loosen the 8 bolts pictured and then slide pedal bars further or closer. Then tighten the 8 bolts to lock in position



0

O

ADJUSTABILITY

4 X ADJUSTABLE FEET











Before use and for rigidity, ensure that all nuts and bolts tightened. All nuts and bolts should be checked regularly and tightened if necessary. If not checked regularly, bolts can loosen and components may become detached and cause injuries.





NEED ASSISTANCE?

If you require any support with your product please contact our friendly team at:

support@nextlevelracing.com

for a prompt response.

ASSEMBLY VIDEO:





SHOP THE RANGE



WHEEL STAND DD



SINGLE FREE STANDING MONITOR STAND



TRIPLE FREE STANDING MONITOR STAND



GTULTIMATE COCKPIT



FLIGHT COCKPIT



GTTRACK COCKPIT





F-GT COCKPIT

MOTION PLATFORM V3

TRACTION PLUS MOTION





For assistance please contact: support@nextlevelracing.com